



Technical data

		Substance
Material	EPDM	
Attribute	Regulation	Value
Colour	black	
Exposure time	6 months	
Application temperature	above -10 °C ; 14 °F	
Temperature resistance	permanent -40 °C to 150 °C ; -40 °F to 302 °F	
Storage	cool and dry	

Area of application

For quick and permanent sealing of penetrations with several cables. Sets for up to 16 cables with a diameter of 4.8-12 mm (3/16"-1/2"), including template and punching tool. Stick with TESCON VANA (included in the double packaging unit).

Advantages

- ✓ Complete set for up to 16 cables
- ✓ Secure bond, quick and secure sealing
- ✓ High-quality EPDM, extremely flexible and elastic, no excess bushing
- ✓ Waterproof, also suitable for penetrations in façades and roof linings
- ✓ Cables can be still be pulled or pushed
- ✓ Construction in adherence with standards: for airtight bonding in accordance with DIN 4108-7, SIA 180 and RT 2012
- ✓ Excellent values in the hazardous substance test, has been tested according to the ISO 16000 evaluation scheme

Substrates

Before adhesion is carried out, subsurfaces should be brushed off, wiped clean with a cloth or cleaned using compressed air. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior and exterior membranes, other vapour retarder and airtight membranes (e.g. those made of PE, PA, PP and aluminium) as well as other underlay/sarking and wall lining membranes (e.g. those made of PP and PET). Bonding and joints are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood fibre underlay panels).

Pretreatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels and smooth mineral subsurfaces. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces. It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases. Pretreatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

General conditions

The bonds should not be subjected to tensile strain. Press firmly to secure the adhesive tapes in place. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof bonding can only be achieved on vapour retarders or underlay/sarking/facade membranes that have been laid without folds or creases. Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

MOLL
bauökologische Produkte GmbH
 Rheinalstraße 35 - 43
 D-68723 Schwetzingen
 Fon: +49 (0) 62 02 - 27 82.0
 eMail: info@proclima.de

