



### Technical data

Material	
Backing	Special PP fleece
Adhesive	Water-resistant SOLID adhesive
Release film	Siliconised paper

Property	Regulation	Value
Colour		Dark blue
Outdoor exposure		6 months
Bond durability, non-aged/aged	DIN 4108-11	Passed
Can be plastered over		Yes
Installation temperature		Above -10 °C ; 14 °F
Temperature resistance		Permanent -40 °C to 90 °C ; -40 °F to 194 °F
Storage		Cool and dry

### Areas of application

For simple, quick and permanently sealed adhesion of blown-in insulation holes and for repairs.

### Supply forms

Art. no.	GTIN	Length	Width	Weight	Sales unit	Container
10795	4026639016560	180 mm	180 mm	0.52 kg	1	1440
10595	4026639016553	180 mm	180 mm	1.8 kg	1	144

### Advantages

- ✓ Saves time: ready-to-install adhesive plaster, protruding release film is easy to remove
- ✓ Adheres reliably, even if moisture is present: water-resistant SOLID adhesive
- ✓ Subsequent work can be carried out with increased flexibility: 6 months of outdoor exposure
- ✓ Subsequent work can be started quickly: fleece backing can be plastered over directly
- ✓ Construction in adherence with standards: for airtight sealing in accordance with DIN 4108-7, SIA 180 and RE 2020
- ✓ Excellent values in hazardous substance testing, has been tested according to the ISO 16000 evaluation scheme

### Substrates

Clean subsurfaces before sticking. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on surfaces where adhesives are to be applied. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior and exterior membranes, other vapour check and airtight membranes (e.g. those made of PE, PA, PP and aluminium) as well as other roof and breather (WRB) membranes (e.g. those made of PP and PET).

Adhesive bonds are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels). Pre-treatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels and smooth mineral subsurfaces. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces. It is your responsibility to check the suitability of the subsurface; adhesion tests may be necessary. Pre-treatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

### General conditions

The bonds should not be subjected to tensile strain. Rub the adhesive tapes firmly to secure the adhesive bonds. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof sealing can only be achieved on vapour checks, roofing underlays or breather (WRB) membranes that have been laid without folds or creases. Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

Tested for hazardous  
substances according to



---

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

---

**MOLL**  
**bauökologische Produkte GmbH**  
Rheintalstraße 35 - 43  
D-68723 Schwetzingen  
Fon: +49 (0) 62 02 - 27 82.0  
eMail: [info@proclima.de](mailto:info@proclima.de)