



Technical data

Material		
Backing	Special PP fleece	
Adhesive	Water-resistant SOLID adhesive	
Release film	Silicone-coated PE film	

Property	Regulation	Value
Colour		light blue
Strip length		60 mm ; 2 3/8"
Thickness		0.5 mm ; 20 mils
Diameter		140 mm ; 5 1/2"
Outdoor exposure		6 months
Bond durability, non-aged/aged	DIN 4108-11	passed
Can be plastered over		yes
Installation temperature		above -10 °C ; 14 °F
Temperature resistance		permanent -40 °C to 90 °C ; -40 °F to 194 °F
Storage		cool and dry

Areas of application

Self-adhesive patch made with TESCO adhesive tape for interior corners for sealing in indoor and outdoor areas. Adhesion to

- ✓ Vapour-check and airtight membranes made of film and paper
- ✓ Vapour-check and airtight membranes made of hard wood-based panels
- ✓ Underlay and breather (WRB) membranes
- ✓ Wood-fibre underlay panels (pre-treatment with TESCO PRIMER)
- ✓ Adjacent building components made of planed wood, hard plastics or metals, such as windows, doors, beams, ties etc.

Supply forms

Art. no.	GTIN	Length	Width	Contents	Weight
1AR01093	4026639210937	0 mm	0 mm	20 pieces	0.3 kg

Advantages

- ✓ Saves time: simple installation thanks to innovative positioning zone
- ✓ More flexible work: now also works for angles other than right angles
- ✓ Can be easily adapted using a knife or scissors
- ✓ Sticks reliably - even if moisture is present: water-resistant SOLID adhesive
- ✓ Subsequent work can be carried out more flexibly: 6 months of outdoor exposure
- ✓ Subsequent work can be started quickly: fleece backing can be plastered over directly
- ✓ Construction in adherence with standards: for airtight sealing in accordance with DIN 4108-7, SIA 180 and RE 2020
- ✓ Excellent values in hazardous substance testing, has been tested according to the ISO 16000 evaluation scheme

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

MOLL
bauökologische Produkte GmbH
 Rheintalstraße 35 - 43
 D-68723 Schwetzingen
 Phone: +49 (0) 62 02 - 27 82.0
 E-mail: info@proclima.com



Substrates

Clean subsurfaces before sticking. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior and exterior membranes, on other vapour-check and airtight membranes (e.g. those made of PE, PA, PP and aluminium) and on other underlay and breather (WRB) membranes (e.g. those made of PP and PET).

Adhesive bonds are possible with planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.) and hard wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels). Pre-treatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels or on smooth, mineral subsurfaces. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces. It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pre-treatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

General conditions

Taped joints should not be subjected to tensile forces. Rub the adhesive tapes firmly to secure the adhesive bonds. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof sealing can only be achieved on vapour checks, roofing underlays or breather (WRB) membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

Tested for hazardous
substances according to



The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

MOLL
bauökologische Produkte GmbH
Rheintalstraße 35 - 43
D-68723 Schwetzingen
Phone: +49 (0) 62 02 - 27 82.0
E-mail: info@proclima.com

