

Installation instructions

ADHERO Floor Drain

Installation of the ADHERO Floor Drain



1. Preparation

Drill a hole with a diameter of at least 70 mm through both the SOLITEX ADHERO and the structure underneath it.

Clean sub-surfaces before taping. Adhesion is not possible on frozen surfaces. There must be no water-repellent substances (e.g. grease or silicone) on materials to be taped over. Sub-surfaces must be sufficiently dry and stable. If necessary, remove any moisture with a wet-and-dry vacuum cleaner.

3. Connect drainage pipe

Connect the plastic pipe or temporary downpipe to the outlet of the floor drain and secure it to prevent it slipping off. Ensure the drainage water is piped out of the building reliably.



2. Installation

Insert the floor drain into the drillhole (if necessary, secure with countersunk screws) and tape it to the SOLITEX ADHERO with no folds or creases using TESCON VANA.

This adhesive tape should cover approx. 30 to 50 mm of both the membrane and the ADHERO Floor Drain. Any water that is collected is to be drained from the building.

© 2024 Pro Clima New Zealand. All rights reserved. The trademarks in this document are registered to Pro Clima or one or more of its affiliates.

The information provided in this document is based on practical experience and current knowledge and was correct at the time of publication. Pro Clima reserves the right to change technical details as developments occur and improvements are made to our products.

Pro Clima recommends reviewing the latest technical data on the www.proclima.co.nz [https://www.proclima.co.nz] website to ensure the most current document version.

PRO CLIMA NEW ZEALAND

Upper North Island: 09 892 9900 [tel:006498929900]

Lower North Island: 04 589 8460 [tel:006445898460]

South Island: 03 327 4925 [tel:006433274925]

Technical: support@proclima.co.nz [mailto:support@proclima.co.nz]

General: welcome@proclima.co.nz [mailto:welcome@proclima.co.nz]

0800 PRO CLIMA (776 254) [tel:0064800776254]