

Installation instructions **ADHERO Floor Drain**

Installation of the ADHERO Floor Drain



1. Preparation

Drill a hole with a diameter of at least 70 mm (2 3/4") through both the SOLITEX ADHERO and the supporting element

Clean subsurfaces before sticking. Adhesion is not possible on frozen surfaces. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable. If necessary, remove any moisture with a wet vacuum cleaner.

3. Connection

Connect the plastic pipe or temporary downpipe to the outlet of the floor drain and secure it to prevent it slipping off. Ensure the drainage water is piped out of the building reliably.



2. Installation

Place SOLITEX ADHERO 1000/3000 in position at this marking, align it exactly in the longitudinal direction and stick the first 30 cm (1 1/4") to the subsurface.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

MOLL

bauökologische Produkte GmbH

Rheintalstraße 35 - 43

D-68723 Schwetzingen

Fon: +49 (0) 62 02 - 27 82.0

eMail: info@proclima.de