

# Installation instructions

## SOLITEX ADHERO® VISTO

### Transparent protection of floors during the construction period



#### 1. Check the subsurface

Clean coarse dirt from the subsurface and remove any protruding elements (e.g. wood splinters or screws) so that the membrane will not be damaged during installation.



#### 2. Remove loose material

Remove any loose material.



#### 3.1 Create marking

Mark the position of the first membrane on the subsurface.



#### 3.2 Create marking

Plan the marking and installation in such a way that there is continuous adhesion with the flat surface.



#### 4.1 Install the membranes, making use of the release film splits

Place SOLITEX ADHERO VISTO in position at this marking, align it exactly in the longitudinal direction and stick the first 25 cm to the subsurface.



#### 4.2 Install the membranes, making use of the release film splits

Rub the membranes firmly into place – e.g. using a brush or PRESSFIX XL





#### 4.3 Install the membranes, making use of the release film splits

Stick the next membrane onto the previous membrane with 10 cm of an overlap. Rub the membrane overlap with PRESSFIX XL.



#### 6. Alternative method of sticking membranes to each other

As an alternative method, the membranes can be taped to one another using TESCON VANA. Position the tape centrally and gradually stick it in place with no folds or creases. Rub the tape firmly to secure the adhesive bond.



#### 8. Protection against seepage

A water-resistant adhesive bond is to be created across the entire joint area. Any gaps or defects are to be covered with TESCON VANA in a waterproof manner or, if necessary, filled with ORCON MULTIBOND, for example.



#### 5. Alternative: Stick the membrane to the subsurface in a single step

Only for experienced installers: Roll out the membrane along the marking and gradually stick it to the subsurface.



#### 7. Joints to concrete walls

Joints are to be sealed using the system adhesive tape, which is to cover at least 50 mm of the membrane. Sealed joints with vertical building structures should cover a height of approx. 10 cm (upper edge of subsequent covering layer of component). Areas to be sealed are to be checked beforehand and, if necessary, pre-treated using TESCON PRIMER RP or TESCON SPRIMER.

Before any product from the AEROSANA VISCONN series is applied to create a sealed connection, the membrane is also to be pre-treated with primer.



#### 9. Drainage: Installation of ADHERO Floor Drain

Insert the ADHERO Floor Drain into the drillhole and, if necessary, secure with countersunk screws.



### 10. Seal ADHERO Floor Drain

ADHERO Floor Drain is used to drain water from surfaces and should be sealed using the TESCO VANA system adhesive tape with no folds or creases. The system adhesive tape should cover approx. 30 to 50 mm of both the membrane and the ADHERO Floor Drain. Any water that is collected is to be drained from the building.



### 11. Working carefully

The purpose of this membrane should be explained to all parties involved in the construction project and these parties should be instructed to exercise the necessary care and to use the necessary protection (e.g. protective boards, protective mats). The membranes are intended for single use in accordance with the product data sheet. Small repairs can be carried out using the TESCO VANA adhesive tape. In the case of large-scale or mechanical damage, the membrane should be replaced.

#### Controlled drying out

To speed up drying out of any building structures or membranes that may have become damp, controlled drying of the construction area is recommended (accompanied by heating of the construction area, if necessary).

#### Disposal recommendations

The membranes are non-hazardous waste. Dispose of them in accordance with the locally applicable regulations. Please consult the safety data sheet.

## Substrates

Clean the subsurface before applying the membrane – remove any protruding elements. Adhesion is not possible on frozen surfaces. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. The subsurface must be sufficiently dry and stable.

## General conditions

SOLITEX® ADHERO VISTO is to be installed with the printed side facing the installation technician; it can be installed on stable substrates such as CLT, OSB, chipboard and plywood sheets. Recesses in the substrate – such as slots, grooves, etc. – can lead to increased seepage underneath the membrane and should be avoided. To achieve waterproof installation, the membrane must be installed with no folds or creases. When installing the membrane, always use a brush or the PRESSFIX XL tool to activate the pressure-activating adhesive.

© 2024 Pro Clima New Zealand. All rights reserved. The trademarks in this document are registered to Pro Clima or one or more of its affiliates.

The information provided in this document is based on practical experience and current knowledge and was correct at the time of publication. Pro Clima reserves the right to change technical details as developments occur and improvements are made to our products.

Pro Clima recommends reviewing the latest technical data on the [www.proclima.co.nz](https://www.proclima.co.nz) [https://www.proclima.co.nz] website to ensure the most current document version.

### PRO CLIMA NEW ZEALAND

Upper North Island: 09 892 9900 [tel:006498929900]

Lower North Island: 04 589 8460 [tel:006445898460]

South Island: 03 327 4925 [tel:006433274925]

Technical: [support@proclima.co.nz](mailto:support@proclima.co.nz) [mailto:support@proclima.co.nz]

General: [welcome@proclima.co.nz](mailto:welcome@proclima.co.nz) [mailto:welcome@proclima.co.nz]

0800 PRO CLIMA (776 254) [tel:0064800776254]