

ROFLEX & KAFLEX Grommet Selection Chart

Designed in Germany and tested for 100-year adhesion durability, our grommets provide a reliable, economical seal for weathertightness and airtightness layers, with up to 180 days of UV exposure. Suitable for interior and exterior use with a wide range of underlays and RABs.



Application	Product Name	Best Suited For	Cable/Pipe Diameter Range	Application	Installation Note	Pack Sizes	SKU
Electrical	KAFLEX mono	Single round cable	5 – 12 mm		Self-adhesive	5 pack 100 pack jumbo pack*	13628 1AR00797
Electrical	KAFLEX multi	Up to 16 round cables	5 – 12 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack** 10 pack** big pack*	1AR05056 1AR02181
Electrical	KAFLEX post	Cables that are already installed	Up to 20 mm		Self-adhesive	5 pack	1AR05054
Plumbing/Electrical	ROFLEX 20	Small pipe/conduit	15 – 30 mm		Self-adhesive	5 pack 30 pack big pack* 100 pack jumbo pack*	13605 13606 15912
Plumbing/Electrical	ROFLEX 20 multi	Up to 9 conduits	15 – 30 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack**	12936
Plumbing/Electrical	ROFLEX 30	Small-to-medium pipe/conduit	30 – 50 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack** 20 pack big pack* 100 pack jumbo pack*	16704 16695 1AR00149
Plumbing/Electrical	ROFLEX 50	Medium pipe/conduit	50 – 90 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack** 20 pack big pack* 100 pack jumbo pack*	13608 13609 11362
Plumbing/Electrical	ROFLEX 100	Large pipe/conduit	100 – 120 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack** 10 pack big pack* 100 pack jumbo pack*	13610 1AR02184 11083
Plumbing/Electrical	ROFLEX 150	Large pipe/conduit	120 – 170 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack** 10 pack big pack* 100 pack jumbo pack*	13614 1AR02201 15908
Plumbing/Electrical	ROFLEX 200	Large pipe/conduit	170 – 220 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack** 10 pack big pack* 20 pack big pack*	13615 1AR02202 13616
Plumbing/Electrical	ROFLEX 250	Very large pipe/conduit	220 – 270 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack**	13617
Plumbing/Electrical	ROFLEX 300	Very large pipe/conduit	270 – 320 mm		Seal perimeter with TESCON EXTORA® flashing tape	2 pack**	13618

* Big pack and jumbo pack products only sold per unit. ** All KAFLEX multi products and ROFLEX 30 to 300 variants of 2-pack products include TESCON EXTORA® flashing tape. All ROFLEX 30 to 300 big pack and jumbo pack products do NOT include tape, which must be ordered separately. ©2026 Pro Clima NZ Limited. All rights reserved. Pro Clima and associated logos are trademarks of Pro Clima. Registered office: Level 1, 47 The Esplanade, Petone, Lower Hutt 5012, New Zealand. Course dates, pricing and availability are subject to change. Visit proclima.co.nz for the latest course information and registration details.

ROFLEX & KAFLEX Quick Installation Guide



KAFLEX post

Self-adhesive grommet, up to 20 mm for existing cables



Place the grommet around the cable with the slit facing downwards.



Gradually remove the release paper and adhere the grommet to the subsurface. Remove the remaining release strips and press the flaps around the cable.



Press the apron and flaps firmly onto the substrate to activate the adhesive and ensure a secure bond.



Installation instructions available on page
<https://proclima.co.nz/products/connections/grommets/kaflex-post/>

ROFLEX 20 / KAFLEX mono

Self-adhesive grommet for 1 pipe or conduit, 15 – 30 mm
/Self-adhesive grommet for 1 cable, 5 – 12 mm



Pull the grommet over the pipe or cable conduit and align it in a diamond shape to ensure water runoff.



Remove the release paper.



Use PRESSFIX to firmly press the adhesive apron onto the substrate to activate the adhesive and ensure a secure bond.



YouTube installation video
<https://www.youtube.com/shorts/oFQstYyK10M>

ROFLEX 20 Multi / KAFLEX multi

Multi-duct grommet, 15 – 30 mm /
Multi-cable grommet, 5 – 12 mm



Punch holes in the EPDM template, and pull the tubes through the grommet.



Use TESCON EXTORA to seal the EPDM grommet around its perimeter.



Use PRESSFIX to firmly press the TESCON EXTORA tape strips, activating the adhesive and ensuring a secure bond.



YouTube installation video
<https://www.youtube.com/shorts/tS8XXp-nR1A>

ROFLEX 30/50/100/150/200/250/300

Pipe/conduit grommets, 30 – 320 mm



Pull the grommet over the pipe and align it in a diamond shape to ensure water runoff.



Use TESCON EXTORA to seal the EPDM grommet around its perimeter.



Use PRESSFIX to firmly press the TESCON EXTORA adhesive strips firmly to activate adhesion and ensure a secure bond.



YouTube installation video
<https://www.youtube.com/shorts/K926EiJ0sLA>