

Installation instructions

ROFLEX 20 multi

Installation steps



1. Preparation

Subsurfaces must have sufficient stability and be dry, level and free of dust, silicone and grease. Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



2. Put the template in place

Remove the installation set from its plastic packaging. Place the EPDM grommet on a cardboard underlay. Put the punching template in place and align it with the EPDM grommet so that the edges match.



3. Punch holes

Punch the required number of holes at the markings on the template using a round punch and a hammer.

Note: The subsurface can be damaged by the punching process. If necessary, use a protective layer.



4. Guide the conduits through

Gradually pull the tubes through the grommet. Press the grommet into place so that it rests flat on the subsurface, and align it in place.



5. Stick the grommet

Stick the grommet around its perimeter using the TESCON VANA (or TESCON INVIS) system adhesive tape. Centre the tape and ensure that there is sufficient resistance pressure. Ensure that the overlaps are waterproof in underlay areas (first carry out adhesion at the bottom, then at the left and right, and finally at the top).



6. Rub to secure the adhesive bond

As a final step, rub all adhesive strips firmly to secure the adhesive bond. This work can be carried out more efficiently and in a manner that is kinder to your hands by using the pro clima PRESSFIX application tool. You're finished!

© 2024 Pro Clima New Zealand. All rights reserved. The trademarks in this document are registered to Pro Clima or one or more of its affiliates.

The information provided in this document is based on practical experience and current knowledge and was correct at the time of publication. Pro Clima reserves the right to change technical details as developments occur and improvements are made to our products.

Pro Clima recommends reviewing the latest technical data on the www.proclima.co.nz [<https://www.proclima.co.nz>] website to ensure the most current document version.

PRO CLIMA NEW ZEALAND

Upper North Island: 09 892 9900 [tel:006498929900]

Lower North Island: 04 589 8460 [tel:006445898460]

South Island: 03 327 4925 [tel:006433274925]

Technical: support@proclima.co.nz [mailto:support@proclima.co.nz]

General: welcome@proclima.co.nz [mailto:welcome@proclima.co.nz]

0800 PRO CLIMA (776 254) [tel:0064800776254]