

Installation instructions


ROFLEX 50

Installation steps



1. Pull the grommet over the pipe and align it

Select a grommet to suit the diameter of the pipe, pull it over the pipe, guide it as far as the subsurface and align it as desired.



2. Tape the grommet and rub firmly to secure the adhesive bond

Tape the grommet to the subsurface and rub the tape firmly to secure the adhesive bond. Ensure that there is sufficient resistance pressure. This work can be carried out more efficiently and in a manner that is kinder to your hands by using the pro clima PRESSFIX application tool.



3. Also for exterior use

All ROFLEX grommets can also be used in exterior applications, e.g. for external roof insulation. In this case, it is important to use TESCON VANA (or TESCON INVIS) system adhesive tapes with water-resistant SOLID adhesive.



4. Conduit grommet

ROFLEX 20 is a conduit grommet made from EPDM and an integrated adhesive substrate, which is suitable for pipes with a diameter of 15–30 mm. Pull the grommet over the conduit, gradually remove the release film and then stick the grommet to the subsurface. Rub the grommet firmly to secure the adhesive bond.



5. Grommet for several conduits

Use of the 'ROFLEX 20 multi' grommet for multiple conduits is recommended if a number of conduits are to be reliably integrated into the airtightness layer.

© 2024 Pro Clima New Zealand. All rights reserved. The trademarks in this document are registered to Pro Clima or one or more of its affiliates.

The information provided in this document is based on practical experience and current knowledge and was correct at the time of publication. Pro Clima reserves the right to change technical details as developments occur and improvements are made to our products.

Pro Clima recommends reviewing the latest technical data on the www.proclima.co.nz [https://www.proclima.co.nz] website to ensure the most current document version.

PRO CLIMA NEW ZEALAND

Upper North Island: 09 892 9900 [tel:006498929900]

Lower North Island: 04 589 8460 [tel:006445898460]

South Island: 03 327 4925 [tel:006433274925]

Technical: support@proclima.co.nz [mailto:support@proclima.co.nz]

General: welcome@proclima.co.nz [mailto:welcome@proclima.co.nz]

0800 PRO CLIMA (776 254) [tel:0064800776254]