

Installation instructions

ROFLEX 20

Installation steps



1. Pull pipe/cable through

Clean the subsurface, then pull the grommet over the pipe or cable.



2. Remove the release paper

Remove the release paper around the pipe/cable feed-through.



3. Stick the grommet

Press the grommet into place so that it rests flat on the subsurface, stick and rub firmly to secure the adhesive bond. The PRESSFIX application tool is ideal for this.

You're finished!

© 2024 Pro Clima New Zealand. All rights reserved. The trademarks in this document are registered to Pro Clima or one or more of its affiliates.

The information provided in this document is based on practical experience and current knowledge and was correct at the time of publication. Pro Clima reserves the right to change technical details as developments occur and improvements are made to our products.

Pro Clima recommends reviewing the latest technical data on the www.proclima.co.nz [https://www.proclima.co.nz] website to ensure the most current document version.

PRO CLIMA NEW ZEALAND

Upper North Island: 09 892 9900 [tel:006498929900]

Lower North Island: 04 589 8460 [tel:006445898460]

South Island: 03 327 4925 [tel:006433274925]

Technical: support@proclima.co.nz [mailto:support@proclima.co.nz]

General: welcome@proclima.co.nz [mailto:welcome@proclima.co.nz]

0800 PRO CLIMA (776 254) [tel:0064800776254]