

# Installation instructions

TESCON® **NAIDECK** mono

## Installation steps



### 1. Reliable sealing

TESCON NAIDECK mono has a very free-flowing butyl adhesive. This adhesive is pulled into the hole created when the nail or screw is installed, thus sealing this hole.



### 2. Stick the tape in place

Centre the nail-sealing tape on the counter batten or the exterior membrane to be sealed, and gradually stick it in place.



### 3. Rub the tape firmly to secure the adhesive bond

This step can be carried out in a manner that is kinder to your hands by using the pro clima PRESSFIX application tool.



### 4. Align and fasten the counter batten

Put the counter batten in place and fasten completely using nails or screws. The counter batten and TESCO NAIDECK mono must lie flat on the exterior membrane with sufficient pressure. You're finished!

## Substrates

Clean subsurfaces before sticking. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on surfaces where adhesives are to be applied. Subsurfaces must be sufficiently dry and stable.

TESCON NAIDECK mono can be used on all pro clima exterior membranes, on other underlay and breather (WRB) membranes (e.g. those made of PP and PET) and with MDF panels and wood-fibre underlay panels.

The best results in terms of structural stability are achieved on level, unstructured subsurfaces. It is your responsibility to check the suitability of the subsurface; adhesion tests may be necessary. Pre-treatment with TESCO PRIMER is recommended in the case of subsurfaces with insufficient stability.

## General conditions

Perforation seals and water-resistant adhesive joints will only be effective on roofing underlay membranes that have been installed with no folds or creases. Install TESCO NAIDECK mono continuously between the counter battens and the roofing underlay membrane. This will ensure that any perforations that are created when the roof battens are being fastened will also be sealed. This tape can be applied onto the counter batten or the substrate that is to be sealed. Rub the tape firmly to secure the adhesive bond.

---

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

---

**MOLL****bauökologische Produkte GmbH**

Rheintalstraße 35 - 43

D-68723 Schwetzingen

Fon: +49 (0) 62 02 - 27 82.0

eMail: [info@proclima.de](mailto:info@proclima.de)