Pre-folded corner adhesive tape for interior and exterior use



Technical data

| | Material |
|--------------|--------------------------------|
| Fleece | Special PP fleece |
| Adhesive | Water-resistant SOLID adhesive |
| Release film | Silicone-coated PE film |

| Property | Regulation | Value |
|--------------------------------|-------------|--|
| Colour | | Light blue |
| Thickness | | 0.5 mm ; 20 mils |
| Outdoor exposure | | 3 months |
| Bond durability, non-aged/aged | DIN 4108-11 | Passed |
| Can be plastered over | | Yes |
| Installation temperature | | Above -10 °C ; 14 °F |
| Temperature resistance | | Permanent -40 °C to 90 °C ; -40 °F to 194 °F |
| Storage | | Cool and dry |

Areas of application

Pre-folded corner sealing tape for sticking

- · Airtight adhesive bonds at corners for vapour control membranes and airtight membranes and for wood-based panels (e.g. OSB)
- Windtight adhesive bonds at corners for roofing underlays and breather (WRB) membranes. Joints at windows (incl. skylights) on the outside, for example
- Airtight joints at windows (incl. skylights) and doors on the inside

Splits on release film

Tape width Split (approx.)

50 mm (2") 12 | 38 mm (15/32" | 1 1/2") 60 mm (2 3/8") 25 | 35 mm (1" | 1 3/8")

Supply forms

| Art. no. | GTIN | Length | Width | Splits on release film | Weight | Sales unit | Container |
|----------|---------------|--------|-------|------------------------|--------|------------|-----------|
| 1AR02924 | 4026639229243 | 30 m | 50 mm | 12 38 mm | 0.6 kg | 20 | 420 |
| 1AR02922 | 4026639229229 | 30 m | 60 mm | 25 35 mm | 0.7 kg | 20 | 420 |

Advantages

- ✓ Sticks corners quickly, simply and tidily
- ✓ Permanently reliable adhesion thanks to moisture-resistant adhesive
- ✓ Saves work thanks to pre-folding and exposed first adhesive surface
- ✓ Easy to work with: very malleable fleece backing
- Subsequent work can be started quickly: fleece backing can be plastered over directly
- ✓ Suitable for various construction situations: available in 12/38 and 25/35 mm separations
- ✓ Construction in adherence with standards: for airtight sealing in accordance with DIN 4108-7, SIA 180 and RE 2020
- ✓ Excellent values in hazardous substance testing, has been tested according to the ISO 16000 evaluation scheme

Substrates

Clean subsurfaces before applying tape. Adhesion is not possible on frozen surfaces. There must be no water-repellent substances (e.g. grease or silicone) on surfaces where adhesives are to be applied. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior and exterior membranes, on other vapour control and airtight membranes (e.g. those made of PE, PA, PP and aluminium) and on other underlay and breather (WRB) membranes (e.g. those made of PP and PET).

Adhesion and taped connections are possible with planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), rigid foam insulation materials that can be plastered over, and hard wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels). Pre-treatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels or on smooth, mineral subsurfaces. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of reliability are achieved on high-quality subsurfaces. It is your responsibility to check the suitability of the subsurface; adhesion tests may be necessary. Pre-treatment with TESCON PRIMER is recommended in the case of subsurfaces that have insufficient stability.



General conditions

Taped joints must not be subjected to tensile forces. Once membranes have been taped, the weight of the insulation material must be supported by laths. Adhesion should be supported by additional laths, if necessary. Rub the adhesive tapes firmly to secure the adhesive bonds. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof sealing can only be achieved on vapour control or underlay/facade membranes that have been installed without folds or creases. Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary. When plastering, please observe the recommendations of the plaster manufacturer for non-absorbent subsurfaces. A bonding course may be necessary.









The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](https://proclima.com/service/technical-support).

MOLL

bauökologische Produkte GmbH Rheintalstraße 35 - 43 D-68723 Schwetzingen Fon: +49 (0) 62 02 - 27 82.0

eMail: info@proclima.de

