

Installation instructions

AEROSANA® VISCONN FIBRE white

Application with a brush or scraper



1. Stir the product

Before application from the tin: stir thoroughly.



2. Clean the subsurface

Clean loose material and coarse dirt from the subsurface using a brush, for example.



3. Determine the crack width

AEROSANA VISCONN FIBRE white bridges cracks of up to 20 mm in width.



4. Painting over cracks up to 8 mm in width

Cracks of up to a maximum of 8 mm in width can be simply painted over. Guide the brush flat across the crack so that the gap is completely filled.



5. Filling cracks up to 20 mm in width

For cracks of 8-20 mm in width, apply AEROSANA VISCONN FIBRE white deep into the crack. To do so, the gap must be filled with sealant to a depth of at least half the width of the gap.



6. Closing up holes

Holes of up to a maximum of 70 mm in diameter at their widest point can be closed using AEROSANA FLEECE and AEROSANA VISCONN FIBRE white.



7. Paint the subsurface

Apply AEROSANA VISCONN FIBRE white with a thickness of at least 1 mm around the hole.



8. Apply the fleece

Cut AEROSANA FLEECE to shape and apply this onto the liquid sealant. Avoid cavities. The bridging fleece must be in contact with the masonry over a width of at least 40 mm around the hole.



9. Paint over the fleece

Paint over the entire area of the bridging fleece with AEROSANA VISCONN FIBRE white.



11. Sealing around penetrations

When creating joints to penetrations, clean loose material and coarse dirt from the subsurface with a brush, for example.



12. Determine the fleece strip length

Determining the strip length of AEROSANA FLEECE: The bridging fleece must be in contact with the masonry and the pipe to be bonded over at least 40 mm for each.



13. Cut the fleece strip

Cut a strip of AEROSANA FLEECE in such a way that its width is slightly greater than half the pipe diameter. The strip can then be worked onto the pipe more easily.



14. Paint the subsurface

Apply AEROSANA VISCONN FIBRE white with a thickness of at least 1 mm around the hole and pipe.



15. Apply the first fleece layer

Apply the fleece pieces onto the liquid AEROSANA VISCONN FIBRE white. Ensure that the valleys formed are free of tension.



16. Paint over the fleece

Then apply AEROSANA VISCONN FIBRE white to the fleece strips, the masonry and the pipe.




17. Apply the second fleece layer

Apply additional fleece strips so that the gap is completely closed. Avoid hollows (valleys).



18. Paint over the fleece

To finish, paint over the joint generously with AEROSANA VISCONN FIBRE white.




20. Awkward detail features

AEROSANA VISCONN FIBRE white can be used to achieve airtightness for geometrically challenging joints (e.g. on renovation projects) in a simple and reliable manner.



21. Paint the subsurface

Paint AEROSANA VISCONN FIBRE white with a thickness of at least 1 mm onto the subsurfaces to be sealed. In the case of changes of material or close to corners, the brush-on sealant must be applied onto at least 40 mm of the subsurfaces.



23. Paint over the fleece

Paint the brush-on sealant onto AEROSANA FLEECE in the area around overlaps to ensure they stick to one another. Once all fleece pieces have been fitted, paint all of the joint with AEROSANA VISCONN FIBRE white.



22. Apply the first fleece layer

Cut pieces of AEROSANA FLEECE into shape and apply them onto the wet AEROSANA VISCONN FIBRE white.



24. Protection against moisture

The drying time for the joint created is around 4–24 hours depending on the absorbency of the subsurfaces and the climate conditions. During this time, the joint must be protected against moisture.

Eave refurbishment with AEROFIXX




1. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



2. Spray over birdsmouth joints

In the area around the birdsmouth joints, spray over the joints between rafters and the wallplate with a generous amount of sealant so that any movement of components that occurs can be accommodated.



3. Continue along the rest of the eave

Also apply a generous amount of AEROSANA VISCONN / FIBRE below the rafters in the area around the birdsmouth joints.



5. Spray over the joint

Set the AEROFIXX to spray application and spray over the joint in a generous manner. Apply the sealant to a width of at least 30 mm on the surfaces to be sealed. The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.



7. Stick the joint

After the sealant has fully dried, seal the refurbishment vapour control membrane in an airtight manner using TESCON VANA, for example.



4. Seal wide joints

Switch the AEROFIXX to line application and completely fill the gap (in this case, between the wallplate and the knee wall) with AEROSANA VISCONN / FIBRE.



6. Use as a primer

If required, apply AEROSANA VISCONN / FIBRE as a primer onto timber that the refurbishment vapour control membrane (e.g. DASATOP) will be bonded to subsequently.

Joints at double collar ties with AEROFIXX



1. Initial situation



2. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



3. Check the joint width

Gaps of up to 3 mm can be filled using AEROSANA VISCONN. Use AEROSANA VISCONN FIBRE for wide gaps of up to 20 mm. In this case, the gap must be filled with sealant to a depth of at least half the width of the gap.



4. Set the device

Set the AEROFIXX to line application.



5. Fill the joint

Fill the joint with a sufficient amount of AEROSANA VISCONN / FIBRE.



6. Spray over the joint

Set the AEROFIXX to spray application and spray over the joint in a generous manner. Apply the sealant to a width of at least 30 mm on the surfaces to be sealed. The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.



7. Work on detail features

Areas that are difficult to access can also be sealed conveniently using the spray method.



8. Check the joint

If necessary, seal any gaps with a brush and AEROSANA VISCONN / FIBRE.



9. The finished joint at a double collar tie penetration

Window joint with AEROFIXX



1. Initial situation

Window is installed, window joint has been filled with insulation material.



2. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



3. Cut away any excess insulation material

If necessary, cut away any protruding insulation.



4. Apply masking tape to the window frame

When doing this, leave a strip with a width of at least 6 mm free on the frame for subsequent sealing using AEROSANA VISCONN / FIBRE.

Alternatively, remove the joint insulation to a sufficient extent to create a clean surface for a lateral bond to the side of the window frame.



5. Spray on the sealant

Spray a sufficient amount of AEROSANA VISCONN / FIBRE onto the window frame, the joint insulation and the adjacent masonry. Apply the sealant evenly. Cracks and pores must be closed by flooding them. The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.



6. Continue around the rest of the window

Bond all four sides of the frame to the masonry using AEROSANA VISCONN / FIBRE.



7. Check the joint

If necessary, seal any gaps with a brush and AEROSANA VISCONN / FIBRE.



8. Interior and exterior use

AEROSANA VISCONN / FIBRE can be used for interior and exterior window joints. The installation method is identical in both cases.



9. Remove the masking tape

Remove the protective masking tape immediately after the window joint is sealed.

Remove any traces of AEROSANA VISCONN / FIBRE from the window frame immediately using a damp cloth.

Sealing wall-to-floor joints with AEROFIXX



1. Preparation

Brush off subsurfaces; if necessary, clean with a vacuum cleaner and wipe down.



2. Preparation of taped joints between boards, if required

If the gaps between adjacent wood-based panels have been taped using TESCON RAPIC to create airtight seals, this tape should be covered over with short lengths of TESCON VANA in the area close to the floor where a liquid sealant will be applied. The edges of the TESCON VANA must adhere directly onto the wood-based panel here.



3. Spray setting

Set the AEROFIXX to spray application.



4. Spray over the base joint

Spray the wall-to-floor joint area. Apply the sealant to a width of at least 30 mm on the surfaces to be sealed.

The layer thickness is sufficient when a textured surface ('orange peel') is recognisable.

© 2024 Pro Clima New Zealand. All rights reserved. The trademarks in this document are registered to Pro Clima or one or more of its affiliates.

The information provided in this document is based on practical experience and current knowledge and was correct at the time of publication. Pro Clima reserves the right to change technical details as developments occur and improvements are made to our products.

Pro Clima recommends reviewing the latest technical data on the www.proclima.co.nz [<https://www.proclima.co.nz>] website to ensure the most current document version.

PRO CLIMA NEW ZEALAND

Upper North Island: 09 892 9900 [tel:006498929900]

Lower North Island: 04 589 8460 [tel:006445898460]

South Island: 03 327 4925 [tel:006433274925]

Technical: support@proclima.co.nz [mailto:support@proclima.co.nz]

General: welcome@proclima.co.nz [mailto:welcome@proclima.co.nz]

0800 PRO CLIMA (776 254) [tel:0064800776254]