

Installation instructions

EXTOSEAL[®] MAGOV

Installation steps



1. Measure out the tape

Roll out the tape to the required length and cut to size.



2. Remove the first release film

Fold the tape in the middle and remove the first release paper.



3. Tape onto tube

Place the tape on the tube and tape it around the tube gradually. Ensure sufficient coating of the ends.



4. Tape onto surface

Remove the second release paper completely. Gradually fold the tape onto the surface and piece by piece tape it all around.



5. Rub firmly to secure the adhesive bond

Afterwards, press sealing firmly all around. Ensure that there is sufficient resistance pressure. The pressing aid pro clima PRESSFIX is particularly efficient and protects your hands.



6. Outdoor applications too

EXTOSEAL MAGOV also provides secure joining of penetrations outdoors, e.g. through breather membranes (WRBs) and roofing underlay membranes.

Substrates

Clean substrates before sticking. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on surfaces where adhesives are to be applied. Subsurfaces must be sufficiently dry and stable.

Adhesive bonds are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels) and mineral substrates such as concrete, non-plastered masonry or plaster.

Pre-treatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels. Concrete or plaster substrates must not be sandy or crumbling. Pre-treatment with TESCON PRIMER is recommended in the case of substrates with insufficient stability.

The best results in terms of structural stability are achieved on high-quality substrates. It is your responsibility to check the suitability of the substrate; adhesion tests may be necessary.

General conditions

The bonds should not be subjected to tensile strain. Rub the tape firmly to secure the adhesive bond. Ensure there is sufficient back pressure. Windproof, airtight or rainproof seals can only be achieved on vapour control membranes, roofing underlay membranes or facade membranes that have been laid without folds or creases.

This product can only be worked with if daytime and nighttime temperatures are $> 5^{\circ}\text{C}$ (41°F). If the initial bond is not satisfactory, a solvent (e.g. white spirits) may be applied to the grey butyl rubber side of the tape. The solvent increases the adhesiveness of the butyl rubber at low temperatures.

The tape is self-sealing under the effect of heat.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

MOLL

bauökologische Produkte GmbH

Rheintalstraße 35 - 43

D-68723 Schwetzingen

Fon: +49 (0) 62 02 - 27 82.0

eMail: info@proclima.de