


Installation steps



1. Principle

Fold over the release film so that it protrudes on the back of the patch. The release film will be touching the release film here on the rear.



2. Preparation of the patch

For installation in corner situations, create slits on the release film up to the patch itself using a cutter to suit the fold geometry. Once the release film is removed later, the slits are automatically continued in the area of the patch.



3. Position the patch

Clean and prepare the subsurface. Fold TESCO SANAPATCH, place it in the space to be stuck and align it.



4. Initial attachment of the patch

Pull back the release film a little, initially attach a few millimetres of the patch to the subsurface on the outside and press into place.



5. Remove the release films

Hold the patch in place with one hand. At the same time, remove the protruding part of one of the release films with the other hand.



6. Press into place

Rub TESCO SANAPATCH firmly into place using the pro clima PRESSFIX application tool or by hand.

Substrates

Clean subsurfaces before sticking.

Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on materials to be bonded. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior and exterior membranes, other vapour-check and airtight membranes (e.g. those made of PE, PA, PP and aluminium) as well as other roof and wall lining membranes (e.g. those made of PP and PET).

Bonding and joints are possible on planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.), hard wood-based panels (chipboard, OSB, plywood, MDF and wood fibre underlay panels).

Pretreatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels and smooth mineral subsurfaces. Concrete or plaster subsurfaces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality subsurfaces.

It is your responsibility to check the suitability of the subsurface; adhesion tests are recommended in certain cases.

Pretreatment with TESCON PRIMER is recommended in the case of subsurfaces with insufficient stability.

General conditions

The bonds should not be subjected to tensile strain.

Press firmly to secure the adhesive tapes in place. Ensure that there is sufficient resistance pressure.

Windproof, airtight or rainproof seals can only be achieved on vapour-checking membranes, roof lining membranes or façade membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about the application and construction can be found in the pro clima planning documentation. For queries please call the pro clima technical hotline on +49 (0)6202 278245.

MOLL

bauökologische Produkte GmbH

Rheintalstraße 35 - 43

D-68723 Schwetzingen

Fon: +49 (0) 62 02 - 27 82.0

eMail: info@proclima.de