

# Installation instructions



## Installation steps: Room corner



### 1. Prepare the corner patch

Pre-fold TESCON TANGO and partially remove the release film of the attachment surface.



### 2. Initial attachment

Attach the patch into the corner using the attachment surface. Use PRESSFIX for situations with difficult access.



### 3. Stick the first independent adhesive strip

Position TESCON TANGO in its final position, gradually remove the release films and stick the patch in place. Ensure that adhesion is carried out tightly in the corner and that there are no cavities.



### 4. Rub the patch firmly into place

This step can be carried out in a manner that is kinder to your hands by using the pro clima PRESSFIX application tool.

## Installation steps: skylights



### 1. Determine the depth of the independent adhesive strip

Measure the width of the available attachment surface using a measuring rule.



### 2. Cut to size

Place the measuring rule on the installation edge and cut TESCON TANGO to size.



### 3. Pre-folding

Remove the narrow release film and pre-fold the patch as shown here.



### 4. Sticking

Guide the patch into the groove of the skylight.  
Stick into the groove and onto the vapour control membrane.  
Rub the tape firmly using the pro clima PRESSFIX to secure the adhesive bond.  
Ensure that there is sufficient resistance pressure.

## Substrates

Clean substraces before sticking. Adhesion to frozen surfaces is not possible. There must be no water-repellent substances (e.g. grease or silicone) on surfaces where adhesives are to be applied. Subsurfaces must be sufficiently dry and stable.

Permanent adhesion is achieved on all pro clima interior and exterior membranes, on other vapour control and airtight membranes (e.g. those made of PE, PA, PP and aluminium) and on other underlay and breather (WRB) membranes (e.g. those made of PP and PET).

Adhesive bonds are possible with planed and painted wood, hard plastics and metal (e.g. pipes, windows etc.) and hard wood-based panels (chipboard, OSB, plywood, MDF and wood-fibre underlay panels). Pre-treatment with TESCON PRIMER is required in the case of adhesion to wood-fibre underlay panels or on smooth, mineral substraces. Concrete or plaster substraces must not be sandy or crumbling.

The best results in terms of structural stability are achieved on high-quality substraces. It is your responsibility to check the suitability of the substrace; adhesion tests may be necessary.

Pre-treatment with TESCON PRIMER is recommended in the case of substraces with insufficient stability.

## General conditions

Taped joints should not be subjected to tensile forces. Rub the adhesive tapes firmly to secure the adhesive bonds. Ensure that there is sufficient resistance pressure. Windproof, airtight or rainproof sealing can only be achieved on vapour control membranes, roofing underlays or breather (WRB) membranes that have been laid without folds or creases.

Ventilate continuously and systematically to prevent build-up of excessive humidity; use a dryer if necessary.

---

The information provided here is based on practical experience and the current state of knowledge. We reserve the right to make changes to the recommended designs and processing or to make alterations due to technical developments and associated improvements in the quality of our products. We would be happy to inform you of the current technical state of the art at the time you use our products.

Further information about installation and design details is available in the pro clima planning documentation. If you have any questions, please contact [pro clima Technical Support](<https://proclima.com/service/technical-support>).

### MOLL

**bauökologische Produkte GmbH**  
Rheintalstraße 35 - 43  
D-68723 Schwetzingen  
Fon: +49 (0) 62 02 - 27 82.0  
eMail: [info@proclima.de](mailto:info@proclima.de)